





Paywizard App Operation Manual

Getting started


1. Launch PayWizard and tap the bottom-left corner six times.




2. Click ADMN MENU and enter the password: 99999999



3. Click the Confirm button. The following screen will be displayed:



4. Click the SETTINGS button. The following screen will be displayed:



5. Change Protocol Type to the target protocol.

Protocol Types:

DEFAULT – Use when calling AIDL API

CLOUD MODE – Use PayWizard payment

SERIAL SLAVE – Use USB cable

SERIAL HOST – Use UU cable


MDBS SERIAL – Use MDB

SERIAL EXT – Use physical serial port

SOCKET SERVER – Use network

SERIAL EXT2 – Use RJ45 port

6. Turn on Debug Mode; the Payment Package Name will auto-fill.





7. Turn on Enable exit directly, after that, click Back button in Paywizard AIDL page, it will exit app directly.

FAQ


What's the serial connection?

Solution: Refer to the following picture:





When testing, why can not do transaction in this page?



Solution:

That means Debug Mode is closed.

Follow up above steps to turn on Debug Mode.